

# SUNSET

## 2" FAUXWOOD LOUVERED ARCH

### EASY INSTALLATION INSTRUCTIONS

#### **Package Contents**

- 1 – Sunset Arch
- 3 – Mounting Screws

#### **Mounting Instructions**

1. Place Arch in the center of the window opening to insure proper fit
2. Locate the “three” pre drilled holes in outer frame of the Arch
3. Make sure the Arch is level in the window
4. Using a pencil, mark the hole positions on the frame of the window
5. Drill pilot holes at marks on window frame
6. Use the three mounting screws to fasten Arch to window opening
7. Do not over tighten mounting screws. This could result in damage to Arch.
8. Check to see if Arch is center in the window. This may be adjusted by tightening and/or loosening the mounting screws
9. Manually adjust the louvers to make sure the Arch is operating properly.